

How to Watch ShowBox

ShowBox is an Android App for watching movies and TV Series. WindsorFreeTV has nothing to do with this App, does not provide or control any of the content or streams, and makes no guarantees as to the suitability of this App for any particular purpose.

The ShowBox App requires the use of a Mouse. A wired or wireless mouse can be connected to any of the available USB outlets on your box. Or you can use the optional wireless Key Pad / Touch Pad.

To open the ShowBox App click on the ShowBox icon.

Once the app is open it will populate the screen with either Movie Fan Art or TV Show Fan art depending on what is selected at the top of the page.

To scroll through the fan art use the scroll wheel on your mouse, or drag 2 fingers down the touch pad from top to bottom.

If you wish to search for something, the search tab is in the upper left corner of the screen. Using your mouse or touch pad move the pointer to the search bar and click or tap the touch pad. A keyboard will appear at the bottom of the screen. If the key pad says Chinese in the lower left move your pointer to the Chinese button and click or tap once and it will change to English.

Using the mouse / touch pad move the pointer to each letter and click or tap to spell out your search item. The search is live and will begin showing results with each letter. When you see what you were searching for stop entering letters and move your pointer to that Fan Art and click or tap to select it.

A Watch screen will appear select your resolution and click watch, now wait for your movie to start do not do any more clicking or tapping.